


\* Maj : 10/2007 REV : i

Déterminer la version du tube & de la cloche pour commander certaines pièces (voir tableau ci-dessous)  
Determine the series of the tube & end bell to order some parts (see table below)

	Version origine : Tube & cloche <i>Original version : Tube &amp; end bell</i>	Tube version origine & cloche version A <i>Tube original series &amp; end bell series A</i>	Tube version A & cloche version d'origine <i>Tube series A &amp; end bell original series</i>	Tube version A & cloche version A <i>Tube series A &amp; end bell series A</i>
<b>B</b>	8	13	<del>8</del>	26
<b>C</b>	9	27	<del>9</del>	27
<b>D</b>	20a	21	<del>20a</del>	21

Version d'origine : Tube & cloche  
*Original series : Tube & end bell*

Version A : Tube & cloche INOX  
*Series A : Tube & Stainless Steel end bell*



**ATTENTION** : Tous les index suivis de la lettre a sont des pièces ou ensemble remplacés par la version A  
**WARNING** : All indexes followed by the letter a are replaced by series A parts or assemblies